

Preventative Maintenance Kits & Spare Parts



972 Centerville Road,
Pulaski, New York 13142
(315) 298-5121

ENDURA® PURE™ HYDRONIC CONDENSING BOILERS

ENDURA



PREVENTATIVE MAINTENANCE KIT	PART #
EDR-0750/1000 with PURE Control™ Annual PM Kit	4-50-081000
KIT INCLUDES:	
Endura Ignition Gasket	2-12-001261
Burner Gasket (Qty: 2)	2-12-001270
Combustion Air Filter	2-30-071039
Ignition Assembly with Igniter Bridge	2-20-000135
O-Ring Gasket for Burner Elbow	2-12-000236
Flame Rod Assembly, EDR PURE	2-20-082010

PREVENTATIVE MAINTENANCE KIT	PART #
EDR-1500/2000 with PURE Control™ Annual PM Kit (Metal Mesh Burner)	4-50-082001
KIT INCLUDES:	
Endura Ignition Gasket	2-12-001261
Burner Gasket (Qty: 2)	2-12-001260
Ignition Assembly with Igniter Bridge	2-20-072000
Combustion Air Filter	2-30-000739
O-Ring Gasket for Burner Elbow	2-12-000235
Flame Rod Assembly, EDR PURE	2-20-082010

Spare parts listed on next page.

A consistent preventative maintenance routine is an important part of continuing efficient and reliable operation of your hydronic boiler system. This bulletin details the recommended parts to perform an annual PM of your Fulton boiler(s) along with suggested spare parts to have on hand if the need arises.

Preventative Maintenance of your Fulton boiler should be performed by a factory authorized Service Technician in accordance with the Installation, Operation and Maintenance Manual.

ENDURA

SPARE PARTS	PART #
Ignition Transformer	2-40-000976
Ignition Cable Assembly	5-11-000018
Gas Valve Actuator	2-40-000884
Gas Valve Body (EDR-0750/1000)	2-30-000002
Gas Valve Body (EDR-1500/2000)	2-30-000003
High Gas Pressure Switch	2-40-000390
Low Gas Pressure Switch	2-40-000387
High Limit Aquastat	2-40-000294
Operating Aquastat	2-40-000251
Low Water Probe	2-20-000023
Low Water Relay	2-40-001421
Touch Screen Display	2-45-315001
Blower Motor Assembly (EDR-0750/1000)	2-30-081000-37
Blower Motor Assyembly (EDR-1500/2000)	2-30-071646-37
Inlet/Outlet Water Temperature Sensor	2-50-315302
Combustion Air & Exhaust Gas/Flue Temp Sensor	2-50-315301
Combustion Air Switch	2-30-001266
Blocked Exhaust Switch	2-30-315001
24VDC Power Supply	2-45-315901
CPU for HMI	2-45-315007
Expansion End Unit	2-45-315124
Expansion Module 1	2-45-315121
Expansion Module 2 & 3	2-45-315004
Expansion Module 4	2-45-315005
LMV36 Burner Management	2-40-000476
LMV36 Modbus Module	2-45-000912
8A Controls Fuse	2-45-000384
15A Blower Fuse (EDR-0750/1000)	2-45-000517
25A Blower Fuse (EDR-1500/2000)	2-45-000535



972 Centerville Road
 Pulaski, New York 13142
 (315) 298-5121



Find your solution at:
www.fulton.com

FHS-EDR-PURE_PM-KIT-240220