

Preventative Maintenance Kits & Spare Parts



972 Centerville Road,
Pulaski, New York 13142
(315) 298-5121

PULSE HYDRONIC CONDENSING BOILERS



A consistent preventative maintenance routine is an important part of continuing efficient and reliable operation of your hydronic boiler system. This bulletin details the recommended parts to perform an annual PM of your Fulton boiler(s) along with suggested spare parts to have on hand if the need arises.

Preventative Maintenance of your Fulton boiler should be performed by a factory authorized Service Technician in accordance with the Installation, Operation and Maintenance Manual.

PREVENTATIVE MAINTENANCE KIT	PART #
PHW-300 through PHW-1400 Annual PM Kit	4-50-SP0401
KIT INCLUDES:	
Air Flapper Gasket	2-12-000551
Gas Flapper Gasket	2-12-000552
Spark Plug	2-20-000090
Flame Rod	2-40-001011

PREVENTATIVE MAINTENANCE KIT	PART #
PHW-1400 Annual PM Kit (SOLA only)	4-50-SP0409
KIT INCLUDES:	
PHW-1400 Annual PM Kit	2-12-000551
Gas Flapper Gasket	2-12-000552
Spark Plug	2-20-000090
Flame Rod	2-40-000931

PREVENTATIVE MAINTENANCE KIT	PART #
PHW-2000 Annual PM Kit	4-50-SP0405
KIT INCLUDES:	
Air Flapper Gaskets	2-12-000554
Gas Flapper Gasket	2-12-000552
Spark Plug	2-20-000090
Flame Rod	2-40-001011

Spare parts listed on next page.





ADDITIONAL SPARE PARTS	PART #
Air Switch-Purge Fan	2-30-000232
Air Switch-Proof of Flame	2-30-001334
RM7865C Programmer (Pre-2012)	2-40-000321
Flame Amplifier	2-40-000268
Low water probe 3"	2-20-000023
11¼" Water Probe for Exhaust Decoupler (PHW-300 through PHW-1000)	2-20-000012
Water Probe for Exhaust Decoupler-15" (PHW-1400 through PHW-2000)	2-20-000109
Purge Fan/Motor (PHW-300 through PHW-1400)	2-30-000445
Purge Fan Motor (PHW-2000)	2-40-002000
Purge Fan Wheel (PHW-2000)	2-30-001337
Low Water Cut Off (LWCO) Relay	2-40-000421
Ice Cube Relay	2-40-000131
Blocked Exhaust Switch	2-30-001360
Blocked Intake Switch (PHW-300 through PHW-1000)	2-30-000291
Blocked Intake Switch (PHW-1400/2000)	2-30-000290
Ignition Wire Assembly (PHW-300 through 1400)	4-30-001000
Ignition Wire Assembly (PHW-2000)	4-30-001002
Air Flapper Repair Kit	4-50-RK0420
Flame Rod Bushing	2-35-000879
Spark Plug Bushing	5-11-400090
Type J Thermocouple	2-40-000801
Gas Union Spacer	2-22-000130
Gas Union Assembly	7-37-000201
Air Flapper Bolts	2-22-000125
SOLA Display (Post-2012)	2-40-000932
SOLA Base (Post-2012)	2-40-000923
Mod Motor (Pre-2012)	2-40-000722
Mod Motor (Post-2012)	2-40-003001



972 Centerville Road
 Pulaski, New York 13142
 (315) 298-5121



Find your solution at:
www.fulton.com

FHS-PULSE_PM-KIT-220713